

Tools needed

- a pair of scissors
- a scalpel pointed and sharp
- a scalpel round
- a pair of pointed tweezers
- a pair of flat tweezers
- water (lukewarm)



1. Cut decal as accurately as possible



2. Moisten your fingers slightly



3. Moisten the model slightly



4. Soak decal (approx. 1 minute)



5. Apply decal and position it correctly



6. Tap decal with Q-tips allow to dry afterwards.

Further information

Soaking time: approx. 1 minute
Drying time: approx. 6 hours

Overcoating / clearcoat sealing

All decals are basically scratchproof and are produced using light-resistant digital printing methods. Please note that the decals may only be sealed with solvent-free paints – same applies to spray cans containing propellants. We recommend the clear gloss of Tamiya X22.

Adhesion improvement if you do not overcoat

Should you refrain from a clearcoat, we recommend giving a small amount of „Ponal wood glue“ into the soaking water. By softening the decals in soaking water mixed with „Ponal wood glue“, a long-term adhesion to the model is guaranteed. The „Ponal wood glue“ hardens crystal clear and leaves no stains or residues on model nor decal.